



GARAGE DOOR OPERATOR REPLACEMENT PARTS LIST


OPERATOR HEAD PARTS



LSO & LCO



LDO




LSO, LDO, & LCO


ITEM #	REPLACEMENT PART	PART #
1	REAR LSO& LCO END COVER (WITH LABELS)	HAE00041
2	MAIN LSO COVER (WITH LABELS)	HAE00026
3	MAIN LCO COVER (WITH LABELS)	HAE00042
4	FRONT LSO COVER (WITH LABELS)	HAE00028
5	FRONT LCO COVER (WITH LABELS)	HAE00043
6	LSO & LCO LENS COVER (FITS BOTH ENDS)	220918
7	LSO MOTOR	220919
8	LCO MOTOR	220919
9	1/3 HP LDO COVER (WITH LABELS)	HAE00011
10	1/2 HP LDO COVER (WITH LABELS)	HAE00012
11	LDO LENS COVER	217645
12	LDO MOTOR	217881
13	CONTROL BOARD (LOGIC/RECEIVER/TORQUE)	HAE00040
14	LAMP SOCKET ASSEMBLY	218014-02
15	1/3 HP CAPACITOR (43-53 MFD) <i>FOR LDO33 ONLY</i>	219109
16	1/2 HP CAPACITOR (53-64 MFD) <i>FOR LDO50 ONLY</i>	219110
17	3/4 HP CAPACITOR (65 MFD) <i>FOR LCO75 ONLY</i>	232168
18	HELICAL AND WORM GEARS (WITH GREASE)	HAE00047
19	HELICAL GEAR (WITH GREASE)	HAE00048
20	LIMIT SWITCH ASSEMBLY	HAE00004

GARAGE DOOR OPERATOR REPLACEMENT PARTS LIST

DC OPERATOR HEAD PARTS




LDCO 800



LDCO 850/852

ITEM #	REPLACEMENT PART	PART #
1	LDCO CONTROL BOARD, BBU COMPATIBLE (800)	HAE00061
2	LDCO FRONT COVER (WITH LABEL) (800)	HAE00051
3	BATTERY BACKUP UNIT (800)	BBU
4	LDCO ENCODER BOARD (800/850/852)	HAE00058
5	LDCO MAIN COVER (WITH LABELS) (800/852)	HAE00052
6	LDCO LIGHT LENS (800/852)	228152
7	LDCO MOTOR (WITH ENCODER) (800/850/852)	HAE00057
8	LED PANEL (850)	10014504-01
9	ASSY, FRONT COVER	HAE00071
10	KIT, PCBA, LDCO (850/852)	HAE00070
11	TRANSFORMER (850/852)	10012046
12	BATTERY HOUSING (850)	10015410-004
13	BATTERY AND HOUSING (850)	BATT54BOX
14	COVER, MAIN (852)	10015922-01
15	BRACKET KIT (852)	10016007
16	BATTERY HOUSING (852)	10015932-001
17	LED PANELS (852)	10014504-02
18	BATTERY (850/852)	BATT54

MISCELLANEOUS OPERATOR PARTS




Linear

GARAGE DOOR OPERATOR REPLACEMENT PARTS LIST


ITEM #	REPLACEMENT PART	PART #
1	DOOR ARM - STRAIGHT	227966
2	DOOR ARM - BENT	227967
3	SAFETY BEAM SENDER & RECEIVER (WITH WIRE)	HAE00002
4	COMPLETE HARDWARE KIT	220205-02
5	WALL STATION (LDO/LSO/LCO/800)	HAE00001
6	WIFI (SMART) WALL STATION (850/852)	LPWWS
7	WIRE KIT (15 SETS OF WIRE AND CLIPS)	HAE00044
8	LDO INSTRUCTIONS AND LABELS	HAE00030
9	LSO INSTRUCTIONS AND LABELS	HAE00031
10	LCO INSTRUCTIONS AND LABELS	HAE00045
11	WIRE CLIP KIT (100 CLIPS)	HAE00019
12	GEL CAP KIT (100 PIECES)	HAE00020

GARAGE DOOR OPERATOR REPLACEMENT PARTS LIST

OPERATOR RAIL PARTS



HBT BELT DRIVE RAILS



HCT and HCI CHAIN DRIVE RAILS

ITEM #	REPLACEMENT PART	PART #
1	HBT DRIVE SPROCKET	220499
2	HBT PULLEY AND BRACKET	218954-03
3	HBT INNER SLIDE ASSEMBLY	HAE00022
4	TROLLEY ASSEMBLY	218189-01
5	7 FOOT BELT ASSEMBLY	HAE00023
6	8 FOOT BELT ASSEMBLY	HAE00033
7	10 FOOT BELT ASSEMBLY <i>INCLUDES BELT CLAMPS INSTEAD OF INNERSLIDE</i>	HAE00065
8	10 FOOT BELT TROLLEY INNERSLIDE <i>INCLUDES TENSIONER</i>	HAE00066
9	10 FOOT BELT TROLLEY OUTERSLIDE	10010527-01
10	DRIVE SPROCKET HOLDER AND BELT CLAMP <i>BELT CLAMP FOR USE ON HBT BELT RAILS ONLY</i>	HAE00049
11	HCT DRIVE SPROCKET	217436
12	HCI DRIVE SPROCKET	227653
13	HCT PULLEY AND BRACKET	HAE00014
14	HCT TURNBUCKLE ASSEMBLY	HAE00013
15	HCT INNER SLIDE ASSEMBLY	HAE00018
16	CENTER SUPPORT BRACKET	CSB
17	7 FOOT CHAIN ASSEMBLY	HAE00015
18	8 FOOT CHAIN ASSEMBLY	HAE00032
19	10 FOOT CHAIN ASSEMBLY	HAE00017
20	12 FOOT CHAIN ASSEMBLY	HAE00046